

## APPLICATION

- 1. Cut the material in reverse with the recommended blade
- 2. Weed the excess material
- 3. Heat press on the garment at 320°F & Protect the polyester carrier with silicone paper 20 sec medium pressure
- 4. Peel the carrier off when cold

